

NOTES:

1. THIS CONCEPTUAL DETAIL IS A GUIDE FOR INSTALLATION OF NICHIIA PRODUCTS. ARCHITECTS/ENGINEERS/ CONTRACTORS ARE RESPONSIBLE FOR SUCCESSFUL APPLICATION WHICH DEPENDS UPON SUBSTRATE DESIGN AND CONSTRUCTION BUILT IN ACCORDANCE WITH BEST PRACTICES AND LOCAL BUILDING CODES.
2. SHEATHING REPRESENTED HERE IS 1/2" PLYWOOD OR 7/16" OSB (FOR OTHER THICKNESSES ADJUST ACCORDINGLY).
3. BLIND FASTENERS MUST BE MIN. 1/2" FROM END OF BOARD FOR BUTT JOINTS AND CORNERS AND 1" FROM TOP EDGE.
4. CUT ENDS OF BOARD MUST BE SEALED WITH PRIMER, PAINT OR SEALANT.
5. STARTER STRIP TO BE A CUT PIECE OF 5/16" NICHIBOARD, FS1005 SPACER, PVC OR PRESSURE TREATED LUMBER. SHOWN HERE IS 1-1/2" X 5/16" RIPPED DOWN NICHIBOARD STARTER.

